

Craftsman Kits and castings in HO and O Scale

The following are basic instructions to assemble the HO garage with interior details. First check the parts and clean up any flash. The base as in the picture below you will notice

the slots in the base to place the building sides. Make sure all the sides fit in the correct slots. You may have to sand some of the building sides to make them fit. Then I suggest that you pre paint the sides and base before you assemble the kit. I start with a good primer I use Krylon Camouflage the #4291 Khaki color. I do not wash the casting I just spray this primer on. Just hit the castings with a light coat so you do not cover the detail. I will not cover painting since that is a complete different subject.

Before you insert the walls into the base slots make sure the wall are not warped. If they are use a hair dryer to warm the resin until it is pliable and then hold the resin piece how you want it until it cools.

Next start assembly I glued the left side of the garage wall in the base slot first. Then the back wall as you see in the photo on the right. Make sure the walls are snug down in the slots in the base before you glue anything.

Before you glue the front wall in make the decision if you want an open shed front like the picture on the right or a garage with doors etc.

The roof you do not glue so you can remove it to view the interior.

Well that's about it I hope you enjoy the model.

Rick Rusty Rail





